

POOL FINDER

LONG RANGE WATER DETECTOR



USER MANUAL

DEVICE AND IT'S COMPONENTS

1) The Long Range System :



2) Handle



3) Receiving Antenna



4) Transmitting Antenna



WORKING PROCEDURE

1) Connect Handle to Device :




2) Connect Receiving & Transmitting Antennas





DEVICE OPERATING STEPS


- 1) ON the Device By ON- OFF Switch
- 2) Start the Device by pressing the start button on the keypad
- 3) The Device Works on 3 Languages (German, English, French) Select your option by OK Button on the keypad.
- 4)After Selecting Language the range will appear on display you can select between (250M/500M/750M/1000M)
For Example (Choose 1000M by pressing UP (or) DOWN buttons on the keypad.
- 5)Increase the receiving antenna length to get more signal strength
- 6) After Selecting the range, the search screen will appear
Which will start the device will give beep sound
- 7)The user should position towards north while starting



- 8) Start the searching by holding the device
 - a) If the target is on the right side means the device will turn right side
 - b) If the target is on the left side means the device will turn left side
 - c) When you pass the target the device will turn to the back
 - d) Then you can stop & point the target 1M square
 - e) After Detecting the target confirm the target from each direction



f) To determine the depth of the target stand above the target and turn 45 degrees and walk straight a head until the device reverse to back



g) Measure the distance between the device turning back point to the starting point

h) Multiply the measuring distance into 10

For Example: The Distance between center point and the device turning point is 20feet than the depth will be $20 \text{ feet} \times 10 = 200\text{feet}$ is the depth.

When you move on to the center point by closing the receiving antenna the device will rotate in the circular motion.

Precautions

- ✓ Please be sure that all precautions taken against risks.
- ✓ Do not use your device while it is raining or on extremely wet floor.
- ✓ Turn on your device after you make sure that all parts are in place.
- ✓ Make sure that battery of your device is fully charged before scanning.
- ✓ If the device starts to give a beep sound, close the device and recharge the battery.
- ✓ We recommend reading the user manual before starting work on the device to understand everything and to avoid mistakes during the search.
- ✓ After the device starts making sound and turns off automatically, put the battery on charge and do not try to start the device without charging the battery.
- ✓ Main unit of the device is under warranty against all electronic breakdowns for two (2) years.
- ✓ Damages caused by user errors (laying open the main unit, hits, harms etc.) are not within this warranty.
- ✓ Battery and antenna are also not within this warranty.
- ✓ You should follow the instructions in this user manual strictly to minimize the possible faults and to use your device correctly.

Zeo Detect

World's Best Detectors



Zeo Detect Company

Address: Dernburgstr.33

14057 Berlin, Germany

Phone No: +4933839066343

Email: info@zeodetect.de

Website: www.zeodetect.de

World wide Marketing by
Zeo World Group

Address: 2020 Pennsylvania Ave,

NW Suite 320, Washington, DC 20006

Phone No: +1 9142305090

Watsapp No: +1 9142305090

Email: info@zeodetect.de

Website: www.zeodetect.de